

ISSUE	Model	Reason	Solution
PORTABOOM® Unit / Arm not operating	PB3000/ PB3000L	Boom Arm not installed in Billet	Ensure Boom Arm is installed at all times during operation.
PORTABOOM® Unit / Arm not operating	PB3000/ PB3000L	Boom Arm not returning to vertical position	Advise to only Power OFF when the Boom Arm is in the vertical position. This issue may occur if the PORTABOOM unit is Powered OFF when Boom Arm is horizontal – If so, Follow these steps: Power on the PORTABOOM unit. Open the large swing door. Locate the white controller box on the right-hand side. Press the OPEN button on the box. Once Boom Arm is in vertical position – turn unit OFF, wait 5 seconds, Turn unit ON – and continue the self-test cycle (see User Manual) prior to operating.





PORTABOOM® Unit / Arm not operating	PB3000L	Toggle switches in wrong position	Check toggle switches on side panel – All switches MUST be in the down position (OFF) in order for boom to function in STANDARD Up/Down operation. • Turn unit OFF – move all switches to down position – Turn unit ON.
PORTABOOM® Unit won't turn on	PB3000/ PB3000L	Wiring Unplugged or not secured	When ON, a green light is illuminated on the Control Unit (located above the ON/OFF switch) If it is not illuminated, open large swing door and check all cabling is plugged in and secure. If all plugged and secure, call Distributor/Manufacturer
PORTABOOM® Unit won't turn on	PB3000/ PB3000L	12v Battery Fuse Blown	Open large swing door and check the fuse on the positive (red) terminal (see images). If fuse blown, contact manufacturer for a replacement fuse.





			Patient No: 2015101178 PB3000
PORTABOOM® Unit will not charge	PB3000/ PB3000L	Anderson plug disconnected	When charging, the 'battery full' light on the Control Unit will be flashing blue (when fully charged – will be solid blue) If not illuminated, open large swing door and follow red/black cables from battery terminal, up towards the top section. You will see red/black Anderson plugs. Confirm these plugs are securely connected.





PORTABOOM® Unit will not charge	PB3000/ PB3000L	Charging unit failed	 Unscrew the four bolts securing the top lid. Image (a) Gently remove lid. Image (b) Plug unit into 240v outlet to charge unit - and switch ON unit. Check that status lights are visible on charger. Image (c) If no lights visible, please contact manufacturer. (a) (b) (c)
PORTABOOM® Unit will not charge	PB3000/ PB3000L	Charging Lead	Ensure the battery charger lead is securely connected to the rear of the 240V outlet located on the side of the PORTABOOM unit. Check that the charging lead is firmly connected to the power point and the power point is turned on.





			Check Charging Lea	-	sed wiring, and tha	at the test and tag label
			- PORTABOOM UN POWER.	ERATORS ON PORTA	NED TO RUN ON PE	
Remote control distance is too short	PB3000/ PB3000L	Antenna coaxial connection to main PCB	Check that the Ant Image (b)	enna SMA connections is securely tighten (b)	n is firmly tightene	d on the main PCB.





Remote control distance is too short	PB3000/ PB3000L	Remote control battery power is low	Open the remote control casing and replace with a new same type of battery.
PORTABOOM® Remote not pairing	PB3000/ PB3000L	User not pairing correctly	Press and hold the button on remote for 10 seconds. A red light will illuminate on the top of remote (if no light – change battery) AT THE SAMETIME - press and hold the 'Program' button on the side panel of PORTABOOM for 10 seconds. Remote is now paired.
PORTABOOM® Arm does not work smoothly	PB3000/ PB3000L	STOP sign mounted in wrong position	If Boom Arm tends to bounce on Up/Down operation, STOP sign may be located too far away from Unit. Bring the STOP sign closer to PORTABOOM unit – advise to mount at the end of the first section (not on the extendable section)





PORTABOOM® Arm does not work smoothly	PB3000/ PB3000L	Unit not stabilised correctly	Lock in both brakes. Indicate the description of the correctly that stability legs are fully extended and engaged correctly.		
PORTABOOM® 6 metre Arm does not work smoothly	PB3000/ PB3000L	Motor Shaft requires adjustment	In order to operate a 6m Boom Arm, the internal shaft needs to be adjusted. Open the door and loosen the 2 lock-nuts at either side of double-threaded bolt. Loosen double-threaded bolt until play in springs is achieved. Image (a) Now undo the large Hex bolt connecting shaft to motor. Reposition shaft in either the left or middle hole. Retighten all nuts/bolts and operate. Image (b) (a) (b)		





PORTABOOM® 6 metre Arm does not work smoothly	PB3000/ PB3000L	STOP sign in wrong position	If Boom Arm tends to bounce on Up/Down operation, STOP sign may be located too far away from Unit. Bring the STOP sign closer to PORTABOOM unit – advise at the end of the first section (not on the extendable section)
PORTABOOM® won't fully charge off Solar Panel	PB3000/ PB3000L	Bad Light	RECOMMEND: fully charge the battery prior to initial use If there has been bad light, charge will be affected – Recommend charging via 240V at regular intervals
		Bad connection	Check cables are connected and secure

